



Nori® Porcine S100P ELISA Kit-DataSheet

S100 calcium-binding protein P (S100P) is a protein that is encoded by the S100P gene.^[1] S100P is a member of the S100 family of proteins containing 2 EF-hand calcium-binding motifs. S100 proteins are localized in the cytoplasm and/or nucleus of a wide range of cells, and involved in the regulation of a number of cellular processes such as cell cycle progression and differentiation. S100P, in addition to binding Ca²⁺, also binds Zn²⁺ and Mg²⁺. This protein may play a role in the etiology of prostate cancer. S100P contributes to promoter demethylation and transcriptional activation of SLC2A5 to promote metastasis in colorectal cancer.[2] Down-regulation of S100P induces apoptosis in endometrial epithelial cell during GnRH antagonist protocol.[3] S100P acts as a target of miR-495 in pancreatic cancer through bioinformatics analysis and experimental verification.[4] S100P stimulates cell proliferation and survival via receptor for activated glycation end products (RAGE).[5] Anterior gradient protein 3 and S100 calcium-binding protein P levels in different endometrial epithelial compartments may play an important role in recurrent pregnancy failure.[6] S100P Interacts with p53 while pentamidine inhibits this interaction. [7] S100P has been shown to interact with EZR^[8] and RAGE.^[9] The interactions between S100P and RAGE are disrupted by cromolyn^[10] and pentamidine.^[9]

References

1. Becker T, et al. (1992). *Eur. J. Biochem.* **207** (2): 541–7.
2. Lin M, et al. (2021) *Br J Cancer* 125 (5), 734-747.
3. Zhang D, et al. (2021) *Reprod Biol Endocrinol* 19 (1), 99.
4. Jiang PF, et al. (2021) *Kaohsiung J Med Sci* 37 (7), 562-571).
5. Arumugam T, et al. (2004). *J. Biol. Chem.* **279** (7): 5059–65.
6. Tempest N, et al. (2021) *Int J Mol Sci* 22 (8), 3835
7. Katte RH, et al. (2021) *Biomolecules* 11 (5), 634.
8. Arumugam T, et al. (2004). *J. Biol. Chem.* **279** (7): 5059–65.
9. Penumutchu SR, Chou RH, Yu C (2014). *PLOS ONE.* **9** (8): e103947.
10. Penumutchu SR, et al. (2014). *Biochem Biophysical Res Communication.* **454** (3): 404–409

PRINCIPLE OF THE ASSAY

This ELISA kit is for quantification of S100P in Porcine samples. This is a shorter ELISA assay that reduces time to 50% compared to the conventional method, and the entire assay only takes 3 hours. This assay employs the quantitative sandwich enzyme-linked immunoassay technique and uses biotin-streptavidin chemistry to improve the performance and the sensitivity of the assays. An antibody specific for Porcine S100P has been pre-coated onto a microplate. Standards and samples are pipetted into the wells and any S100P present is bound by the immobilized antibody. After washing away any unbound substances, a detection antibody specific for Porcine S100P is added to the wells. Following wash to remove any unbound antibody reagent, a detection reagent is added. After intensive wash a substrate solution is added to the wells and color develops in proportion to the amount of S100P bound in the initial step. The color development is stopped, and the intensity of the color is measured.

This package insert must be read in its entirety before using this product.

Storage

Store the kit at 4°C. The kit can be used in 6 months.



Nori® Porcine S100P ELISA Kit-DataSheet

MATERIALS PROVIDED

Description	Quantity	Description	Quantity	Description	Quantity
Antibody Precoated Plate	1	20 x PBS	1	Substrate Solution	1
Detection Antibody	1	20 x Assay Buffer	1	Stop Solution	1
HRP Conjugate	1	MSDS	1	DataSheet	1
Standard	3	CoA	1	96-well plate sheet	1

Bring all reagents to room temperature before use.

Reagent Preparations

Porcine S100P Detection Antibody (1 vial) – The lyophilized Detection Antibody should be stored at 4°C for up to 6 months, if not used immediately. Centrifuge for 1 min at 6000 x g to bring down the material prior to open the vial. The vial contains sufficient Detection Antibody for a 96-well plate. Add 200 µL of sterile 1 x PBS and vortex 30 sec. If the entire 96-well plate is used, take 200 µL of detection antibody to 10.5 mL of 1 x PBS to make **Working dilution of detection antibody** and mix thoroughly prior to the assay. If the partial antibody is used store the rest at -20°C until use.

Porcine S100P Standard (3 vials) – Each of the lyophilized Porcine S100P Standard vial contains the standard sufficient for generating a standard curve. The unreconstituted standard can be stored at 4°C for up to 6 months if not used immediately. Centrifuge for 1 min at 6000 x g to bring down the material prior to open the tube. Add 500 µL of 1 x Assay Buffer to make the high standard concentration of 4 ng/ml and **vortex for 1 min**. A seven-point standard curve is generated using 2-fold serial dilutions in the Assay Buffer, **vortex 30 sec** for each of dilution step.

HRP Conjugate (55 µl) – Centrifuge for 1 min at 6000 x g to bring down the material prior to open the vial. The vial contains 55 µL HRP Conjugate sufficient for one 96-well plate. If the volume is less than 55 µL, add sterile 1 x PBS to reach 55 µL and vortex 10 sec. Make 1:200 dilutions in 1 x PBS. If the entire 96-well plate is used, add 53 µL of HRP Conjugate to 10.5 mL of 1 x PBS to make **working dilution of HRP Conjugate** and vortex 30 sec prior to the assay. The rest of undiluted HRP Conjugate can be stored at 4°C for up to 6 months. DO NOT FREEZE.

20 x PBS, pH 7.3, 25 mL- Dilute to 1 x PBS with deionized distilled water and mix well prior to use.

20 x Assay Buffer, 20 mL- Dilute to 1 x Assay Buffer with 1 x PBS prior to use.

Substrate Solution, 10.5 mL.

Stop Solution, 5.5 mL.



Nori® Porcine S100P ELISA Kit-DataSheet

Assay Procedure

1. All procedures are conducted at room temperature (20-25 °C) and ensure **equal pipetting/dispensing** at each step and remove air bubbles in the wells for all steps.
2. Lift the plate cover and cover the unused wells or reseal the unused strips in the aluminum bag with desiccant at 4 °C. **Vortex the standards and samples for 10 sec** before applying to the plate. Add 100 µL of **diluted sample** (see below) or **standard** per well and use duplicate wells for each standard or sample. Cover the 96-well plate and incubate for **2 hours**. Attention: **MUST vortex standards and samples for 10 sec before pipetting to the wells!**
3. Aspirate each well and wash with 300 µL of **1 x Assay Buffer** for two times. Wash by filling each well with 1 x Assay Buffer using a multi-channel pipette, manifold dispenser or auto-washer. Complete removal of liquid at each step is essential for good performance. After the last wash, remove any remaining Assay Buffer by aspirating or by inverting the plate and blotting it against clean paper towels.
4. Add 100 µL of the **working dilution of Detection Antibody** to each well. Cover the plate and incubate for 1 hour.
5. Repeat the aspiration/wash as in step 3.
6. Add 100 µL of the **working dilution of HRP Conjugate** to each well. Cover the plate and incubate for 20 minutes. Avoid placing the plate in direct light.
7. Repeat the aspiration/wash as in step 3 but **wash 4 times** instead.
8. Add 100 µL of **Substrate Solution** to each well and observe the color development every 1-2 mins. Incubate for up to **30 minutes (depending on signal. Stop** the reaction when it turns to dark blue in the highest standard wells). Over-incubation of the substrate will result in overflow of high standard and thus should be avoided. Avoid placing the plate in direct light.
9. When it gets to dark blue in the highest concentration of standard wells, add 50 µL of **Stop Solution** to each well to stop the reaction. Gently tap the plate to ensure thorough mixing.
10. Determine the optical density of each well immediately, using a microplate reader set to 450 nm. If wavelength correction is available, set to 540 nm or 570 nm. If wavelength correction is not available, subtract readings at 540 nm or 570 nm from the readings at 450 nm. This subtraction will correct for optical imperfections in the plate. Readings made directly at 450 nm without correction may be higher and less accurate.

Sample dilution: Samples should be diluted with one volume of 1 x Assay Buffer and **vortex for 1 min** prior to assay. If the OD value still exceeds the upper limit of the standard curve, further dilution is recommended till it falls in the detection range and the dilution factor must be used for calculation of the concentration.

Precaution and Technical Notes

1. It is critical to follow the procedure step by step otherwise appropriate color development may not occur as expected and make sure no air bubbles in wells before adding reagents.
2. A standard curve should be generated for each set of samples assayed. Thorough mixing of standards at each of dilution steps is critical to acquire a normal standard curve and **vortex again (10 sec) before pipetting to the 96-well plate.**
3. HRP Conjugate contains enzyme, DO NOT mass up with Detection Antibody.
4. The Stop Solution is an acid solution, handle with caution.
5. This kit should not be used beyond the expiration date on the label.
6. A thorough and consistent wash technique is essential for proper assay performance.
7. Use a fresh reagent reservoir and pipette tips for each step.
8. It is recommended that all standards and samples be assayed in duplicate.
9. Avoid microbial contamination of reagents and buffers. This may interfere with the performance of the assay.



Nori® Porcine S100P ELISA Kit-DataSheet


Calculation of Results

Average the duplicate readings for each standard, control, and sample and subtract the average zero (blank) standard optical density.

Create a standard curve by reducing the data using computer software capable of generating a four-parameter logistic (4-PL) curve-fit. As an alternative, construct a standard curve by plotting the mean absorbance for each standard on the y-axis against the concentration on the x-axis and draw a best fit curve through the points on the graph. The data may be linearized by plotting the log of the S100P concentrations versus the log of the O.D. and the best fit line can be determined by regression analysis. This procedure will produce an adequate but less precise fit of the data. If samples have been diluted, the concentration read from the standard curve must be multiplied by the dilution factor.

The Standard Curve

The graph below represents typical data generated when using this Porcine S100P ELISA Kit. The standard curve was calculated using a computer generated 4-PL curve-fit. For this case, a Bio-Rad iMark™ Microplate Reader and a Microplate Manager 6 Software were used to generate this curve. The correlation coefficient (r^2) is 0.999-1.000.





Nori® Porcine S100P ELISA Kit-DataSheet

Specificity

The following recombinant Porcine proteins prepared at 10 ng/ml were tested and exhibited no cross-reactivity or interference.

ApoAI, BMP7, CRP, HGF, HSP27, IL-1 α , IL-23, IFN γ , MMP-2, PDGF, PLA2G7, prolactin, S100A1, TGF β 1, TLR3, TNF- α , VEGF.

Calibration

This kit is calibrated against Porcine S100P.

Detection Range

62.5-4000 pg/ml

Assay Sensitivity

12 pg/ml

Assay Precision

Intra-Assay %CV: 6; Inter-Assay %CV: 9

Sample Types: Plasma, serum, cell/tissue lysates, cell culture supernatant, synovial fluid (SF), bronchoalveolar lavage (BAL), cerebrospinal fluid (CSF), urine, other biological fluid.

Related products

Porcine S100P Standard

Porcine S100P detection antibody

DECLARATION

THIS REAGENT IS FOR IN VITRO LABORATORY TESTING AND RESEARCH USE ONLY. DO NOT USE IT FOR CLINICAL DIAGNOSTICS. DO NOT USE OR INJECT IT IN HUMANS AND ANIMALS.

**FOR LABORATORY RESEARCH USE ONLY
NOT FOR USE IN PORCINES AND ANIMALS**



Nori® Porcine S100P ELISA Kit-DataSheet

Troubleshooting Guide

Problem	Possible causes	Solution
Poor standard curve	<ul style="list-style-type: none">• Inaccurate pipetting• Insufficient vortexing• OD₄₅₀ too high for the high standard point• Air bubbles in wells.	<ul style="list-style-type: none">• Check pipettes and ensure equal dispensing.• Vortex 30 sec for each of standard dilution steps and vortex again (10 sec) before pipetting to the 96-well plate.• Reduce substrate incubation time• Remove air bubbles in wells by pipette tip.
Low signal	<ul style="list-style-type: none">• Improper preparation of reagents and storage• Too brief incubation times• Inadequate reagent volume or improper dilution• Standard defect	<ul style="list-style-type: none">• Briefly spin down vials before opening. Reconstitute the powder thoroughly. Proper storage of plate and strip and detection antibody after first usage as shown in the datasheet.• Ensure sufficient incubation time including substrate incubation. Increase sample incubation to 2 hours.• Change a Standard vial.
Overflow in the standards	<ul style="list-style-type: none">• Substrate incubation too long• Air bubbles in wells	<ul style="list-style-type: none">• Observe the color development every 1-2 mins and reduce substrate incubation time.• Remove air bubbles in wells• Stop the reaction by adding 50 µl of Stop Solution when it turns to dark blue in the highest concentration of standard wells.
Large CV	<ul style="list-style-type: none">• Inaccurate pipetting and mixing• Improper standard/sample dilutions.• Air bubbles in wells.	<ul style="list-style-type: none">• Check pipettes and ensure accurate pipetting and thorough mixing and equal dispensing.• Use the correct dilution buffers• Remove air bubbles in wells by pipette tip.
High background	<ul style="list-style-type: none">• Reagent reservoir issue• Plate is insufficiently washed and air bubbles in wells.• Contaminated wash buffer• Pipet tip contaminated	<ul style="list-style-type: none">• Use a new reagent reservoir for Substrate Solution.• Increase wash to 4 times before adding substrate and ensure plate washer functions normally. Remove air bubbles in wells by pipette tip.• Make fresh wash buffer and wash thoroughly.• Use new pipette tips for blank wells.
No signal detected	<ul style="list-style-type: none">• The procedure was misconducted.• Failure of Substrate or HRP	<ul style="list-style-type: none">• Ensure the step-by-step protocol.• Mix 100 µl of Substrate with 0.5 µl HRP and deep color should develop in 2 min.• Try a new standard vial and use positive control.
Low sensitivity	<ul style="list-style-type: none">• Improper dilutions of standards• Improper storage of the ELISA kit	<ul style="list-style-type: none">• Ensure accurate and thorough dilutions of standards at each step.• Store detection antibody at -20°C after reconstitution, others at 4°C. Keep substrate solution protected from light.